

CARSON®

Lens Cleaner

with Dry Nano-Particle Cleaning Formula

Congratulations on selecting your new Lens Cleaner! In order to achieve optimum performance, please follow instructions for proper use and care.



PRODUCT SPECIFICATIONS


Soft Tip:	Microfiber
Weight:	0.04 lbs
Dimensions:	0.9" x 0.7" x 5.1"

USE FOR




USING LENS CLEANER


1. Move slider up to reveal brush. Wipe away loose dust and debris. Move slider down to retract brush.



2. Remove cap and wipe lens in a circular motion.



3. Replace cap and twist once to replenish tip with cleaning compound.



Customer Service:

If you experience any difficulties, please contact us and we will be happy to help you.



✉ info@carson.com



✉ uksupport@carson.com



✉ eusupport@carson.com

For warranty information, visit www.carson.com/warranty

www.carson.com

Carson Optical 2070 5th Avenue, Ronkonkoma, NY 11779 | Tel: 631-963-5000